

Helpful Hints for System 6:

~Back-up battery charges only when 6 is powered off with AC power supply plugged in. Charge overnight before meet.

~Before power up, confirm you are using a System 6 specific power supply (15 Volt). Other timing equipment uses different voltages. Although different power supply power plugs are interchangeable with your 6 power receptacle, the incorrect input voltage will cause unsatisfactory results along with possible circuit damage.

~Please remove System 6 from pool area between meets (if possible). Use red connector covers to help prevent corrosion.

~Tips for stubborn cable harness contact resistance:
Sometimes you may encounter difficulty making solid connections on various cable attachment positions for your timing system or scoreboard. This is a condition caused from pool chemical corrosion. This oxidation may be quickly removed using a handy product called "Rid-Ox" made by the company Techspray and their Part # is (2112-6S).

Rid-Ox is a spray-on contact cleaner & protector. You may also use a small parts/paint brush or toothbrush to help scrub off corroded deposits. Be sure to apply the Rid-Ox to both the harness and the System 6 connectors. Rid-Ox may be purchased through a Google search supplier, or on-line at:
<http://www.mcmelectronics.com/product/TECHSPRAY-2112-6S-/20-3295>
Also can be purchased from Colorado Time Systems ~ Part # (R-530-016) for \$17.00

**Reminder: Meet Manager connections hook up only to COM 1 on the System 6 with a standard serial cable. Don't forget to check the COM port number on your PC to enter in the Interface menu of Meet Manager.

Problems? 1-970-667-1000

WWW.Coloradotime.com